

USB Driver Setup Instructions

Please select your operating system and follow the step by step instructions:

Windows 98

USB Driver Setup Instructions for Windows 98

Step 1: Connect USB cable to your PC.

Step 2: New hardware should automatically be detected. When prompted to search for new drivers, select "Next".

Step 3: When prompted: "What do you want windows to do?", leave the recommended setting of "Search for the best driver for your device." and select "Next".

Step 4: When prompted where you want windows to search for the driver:

- a. Uncheck "Floppy disk drives".
- b. Uncheck "CD ROM drive".
- c. Select "Specify a location".
- d. Select Browse.
- e. If prompted to insert a disk in drive A, select "Cancel".
- f. Browse to the folder created for your downloaded driver.

1. Locate the folder created for your downloaded driver.
2. Click on the created folder.
3. Click on "OK".

g. Select "Next".

Step 5: When prompted: "Windows is ready to install the best driver for this device. . ." select "Next".

Step 6: When prompted: "Windows has finished installing the software your new hardware device

requires.", select "Finish". Windows will finish installing the USB cable as a high-speed serial port.

Note: If the wireless phone ever fails to respond, unplug the cable for a few seconds, and reconnect it.

Windows ME

USB Driver Setup Instructions for Windows ME

Step 1: Connect the USB cable to your PC.

Step 2: New hardware should automatically be detected. When prompted "What would you like to do?", select "Specify the location of the driver (Advanced)" and then select "Next".

Step 3:

- a. Uncheck "Removable Media" .
- b. Select "Specify a location".
- c. Select "Browse".
- d. If prompted to insert a disk in drive A, select "Cancel".
- e. Browse to the folder created for your downloaded driver.

1. Locate the folder created for your downloaded driver.
2. Click on the created folder.
3. Click on "OK".

f. Select "Next".

Step 4: When prompted: "Windows is now ready to install the best driver for this device. . ." select "Next".

Step 5: When prompted: "Windows has finished installing the new hardware device.", select "Finish"

. Windows will finish installing the USB cable as a high-speed serial port.

Step 6: Important: Remove USB cable, wait a few seconds, reconnect cable.

Note: If the wireless phone ever fails to respond, unplug the cable for a few seconds, and reconnect it. Also if you have a need to restart the PC, do it with the cable disconnected.

Windows 2000

USB Driver Setup Instructions for Windows 2000

Step 1: Connect the USB cable to your PC.

Step 2: When prompted: "Welcome to the Found New Hardware Wizard", select "Next".

Step 3: When prompted: "What do you want the wizard to do?", leave the default recommended setting of "Search for a suitable driver for my device" and select "Next".

Step 4:

a. Under "Optional search locations:"

1. Uncheck "Floppy disk drives".
2. Uncheck "CD-ROM drives".
3. Select "Specify a location".

b. Select "Next".

Step 5:

a. Select "Browse"

b. If prompted to insert a disk in drive A, select "Cancel".

c. Browse to the folder created for your downloaded driver.

1. Locate the folder created for your downloaded driver.
2. Click on the created folder.
3. Select "Open".

d. Select "OK" to continue.

Step 6: Windows will confirm it found the driver for this device, select "Next" to continue.

Step 7: When prompted: "Completing the Found New Hardware Wizard", select "Finish".

Windows XP

USB Driver Setup Instructions for Windows XP

Step 1: Connect the USB cable to your PC.

Step 2: When prompted: "Welcome to the Found New Hardware Wizard", select "Install from a list or specific location (Advanced)" and then select "Next".

Step 3:

a. Uncheck "Search removable media (floppy, CD-ROM...)"

b. Select "Include this in the search".

c. Select "Browse"

d. If prompted to insert a disk in drive A, select "Cancel"

e. Browse to the folder created for your downloaded driver.

1. Locate the folder created for your downloaded driver.
2. Click on the created folder.

3. Click on "OK".

-

f. Select "Next" to continue.

-

Step 4: Windows will warn you that the software drivers have not passed Windows Logo testing. Select "Continue Anyway".

Step 5: When prompted: "Completing the Found New Hardware Wizard.", select "Finish".

-